2.4GHz Wireless Smart Touch Keyboard

Model #: KB3800TPW



User's Manual

PID # 121363-109290
Rev. 100114

All brand name and trademarks are the property of their respective owners

USER'S RECORD:

To provide quality customer service and technical support, it is suggested that you keep the following information as well as your store receipt and this user's manual.

Date of Purchase: _____

Model Number: _____

Product Rev Number (located below the UPC on the package): _____

FCC RADIATION NORM:

FCC

This equipment has been tested and found to comply with limits for Class B digital device pursuant to Part 15 of Federal Communications Commission (FCC) rules.

FCC Compliance Statement

These limits are designed to provide reasonable protection against frequency interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed or used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in television reception, which can be determined by turning the equipment off and on. The user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected to.

CAUTION!

The Federal Communications Commission warns the user that changes or modifications to the unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

PACKAGE CONTENTS:

Your new Keyboard will ship with the following items:

- 2.4GHz Wireless Smart Touch Keyboard
- Mini Receiver
- 2 AAA Batteries
- User’s Manual & Warranty Info.

SYSTEM REQUIREMENTS:

Please be sure that you meet all of the system requirements below to avoid difficulties during installation:

- 100% PC Compatibles
- Windows® 2000, XP, Vista and 7
- Available USB Port

BATTERY INSTALLATION

1. Press and slide the Battery Compartment Cover Release Latch at the bottom of your keyboard to remove the Battery Compartment Cover from your keyboard.

2. Install two AAA batteries into your keyboard following the battery orientation guide in the battery bay.

3. Replace the Battery Compartment Cover back onto your keyboard until it securely locks.

CONNECTING TO A COMPUTER:

NOTE: The pictures shown in this User's Manual are for demonstration purposes only. Your computer or product may look slightly different.

1. Plug the USB connector of your keyboard into an available USB port on your computer.

2. Turn on your computer.
3. Your computer will detect and install the necessary drivers automatically.
4. Your new keyboard is now ready to be used.

USING TOUCHPAD:

The built-in touchpad supports Multi-touch function. Below are the functions of the touchpad.

Action on Touchpad	**Function**
Single finger slide	Move cursor
Single finger tap	Equals to clicking the left button of a mouse
Two finger tap	Equals to clicking the middle button (pressing down the scroll wheel) of a mouse
Three finger tap	Equals to clicking the right button of a mouse
Double tapping with one finger	Equals to double clicking the left button of a mouse
Tap and drag	Use this function to select and move an object or icon.

WARRANTY INFORMATION:

Gear Head, LLC warrants that this product shall be free from defects in materials and workmanship for the reasonable lifetime of the product. If the product is defective, Gear Head, LLC's sole obligation under this warranty shall be at its election, subject to the terms of this warranty, to repair or replace any parts deemed defective. This warranty is for the exclusive benefit of the original purchaser and is not assignable or transferable. THIS WARRANTY IS MADE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, AND ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE TERMS OF THIS WARRANTY, UNLESS OTHERWISE PROHIBITED BY LAW.

Exclusions

To the fullest extent permitted by law, Gear Head, LLC expressly disclaims and excludes from this warranty any liability for damages, including but not limited to general, special, indirect, incidental, consequential, aggravated, punitive or exemplary damages, and economic loss (even if Gear Head™ is informed of their possibility), third party claims against you, including for any loss or damages, and claims or damages related to loss of, or, damage to, your records or data. This warranty does not apply to any product the exterior of which has been damaged or defaced. This warranty will be voided by misuse, improper physical environment, improper repair, acts of God, war or terror, commercial use, and improper service, operation or handling.

Technical Support

Please access Technical Support on the web or contact our technicians at info@pcgearhead.com for help.

www.pcgearhead.com

Gear Head™ provides phone support, 866-890-7115, Monday - Friday from 9:00 am – 5:30 pm Eastern Time. Before calling, please make sure you have available the Model # (located on the front page of your User's Manual) and information regarding your computer's operating system.

Return Merchandise for Service

Any claim under this warranty must be made in writing to Gear Head, LLC, within 30 days after the owner discovers the circumstances giving rise to any such claim, and must include a copy of this warranty document, a receipt or copy of your invoice marked with the date of purchase, and the original packaging. You may contact us on the web at www.pcgearhead.com or by emailing us at info@pcgearhead.com to receive service or request a return service authorization.